

CONTENTS

SECTION 1:	SAFETY	1
	Protective Ground	1.1
	Repair and Adjustment	1.2
SECTION 2:	INTRODUCTION	2
SECTION 3:	INSTALLATION	3
	Supply Connection	3.1
	Heater & Sensor Connections	3.2
	Serial Data Line Connections	3.3
SECTION 4:	OPERATION	4
	First Time Operation	4.1
	Communication Protocols	4.2
	Commands and Responses	4.3
SECTION 5:	COMMAND LIST	5
SECTION 6:	COMMAND SYNTAX	6
SECTION 7:	CALIBRATION	7
SECTION 8:	CALIBRATION CONSTANTS AND NOTES	8
SECTION 9:	THEORY OF CONTROL	9
	General	9.1
	Open Loop Operation	9.2
	On-Off Control	9.3
	Proportional Control	9.4
	Integral Action	9.5
	Derivative Action	9.6
SECTION 10:	THE NON-VOLATILE MEMORY	10
	"batt" warning message	10.1
	Memory Replication	10.2
	Restoration of Original Memory Content	10.3
SECTION 11:	CIRCUIT DIAGRAMS & PARTS SCHEDULES	11

1 SAFETY

The following general safety precautions must be observed during the operation, service and repair of this instrument.

1.1 Protective Ground

To minimise shock hazard the instrument must be connected to an electrical ground. The ground wire (green/yellow) in the instrument AC power cable must be connected to the installation electrical ground system. Do not use extension cords without a protective earth conductor. Do not disconnect the protective ground inside or outside the instrument. Do not have external circuits connected to the instrument when its protective ground is disconnected.

1.2 Repair and Adjustment

Ensure that the instrument is disconnected from the AC power supply (switching off the front panel ON-OFF switch is not sufficient) before the covers are removed or fuses are replaced, otherwise dangerous voltages are accessible. Capacitors inside the instrument and power connector filter, if fitted, may remain charged after removal of AC power. These should be discharged before starting work.

For fault finding and calibration the AC power supply may require reconnection. This work may only be carried out by skilled personnel who are aware of the hazard involved.

2 INTRODUCTION

This manual provides operating and service information for the Oxford Instruments VT Controller model VTC4.

The Variable Temperature Controller (VTC) is intended for use in conjunction with a Varian NMR spectrometer. It is designed to control the sample temperature within the NMR probe. Heating of the sample is by means of a nitrogen gas stream which is warmed by a heater within the probe. The heater is supplied with 0-40v DC from the VTC. For operation below room temperature the gas stream is precooled by passing it through a heat exchanger immersed in liquid nitrogen.

*Not
GFW IV*

The sample temperature is sensed by two thermocouples mounted in the gas stream between the heater and the sample. These are connected in parallel via a potentiometer which allows the ratio of their contributions to be adjusted.

An additional platinum resistance safety sensor is mounted directly on the heater assembly. This enables the heater power to be shut down in the event of a failure of the gas flow. Additional safety features are incorporated to protect the VT probe against operator errors and system faults.

The VTC employs a 4 digit display of temperature covering the range -150.0 to +200.0 degrees C. In addition a Status Lamp allows an operator to observe the current VT status. All control of the VTC is by serial data sent from the spectrometer computer via an RS232C data link. This link also allows the computer to interrogate the VTC. The same link may be used, connected either to a computer or to a standard 9600 baud terminal, to effect a full calibration of the VTC.

The following error conditions may be detected and produce an status message to the computer.

- o/c Thermocouple
- o/c Safety Sensor
- s/c Safety Sensor
- Over-temp at safety sensor
- s/c Output transistor
- Software/uProcessor failure

Over-temperature at the safety sensor initially turns the heater off. If this fails to correct the condition within 5 seconds, it is assumed that either the gas flow has been interrupted, or that an output transistor failure has occurred. In this case a protective relay operates, isolating the heater from the control electronics. Sensor failure on any of the sensors also results in this relay operating.

Once the protective relay has operated the output will remain off. A power down, or an "N" or "C" instruction from the computer is required to release the relay.

An auxillary output port is available on the VTC for control of a gas solenoid of other external devices.

3 INSTALLATION

3.1 Supply Connection

Before applying power to the instrument, ensure that the voltage selector on the rear panel is correctly set for the intended supply voltage.

If necessary, open the voltage selector panel using the slot provided, withdraw the voltage selector and replace it in the correct orientation for the intended voltage. Check that the correct fuses are fitted, then close the voltage selector panel.

Fuse ratings are:

100-120v	1.6A Type T (Slow Blow)
200-240v	0.8A Type T (Slow Blow)

3.2 Heater and Sensor Connections

Connections to the heater, the main sensor (Copper/Constantan Thermocouple) and the safety sensor (Platinum Resistance Thermometer) are by means of a 9 way D-socket on the rear panel. Pin connections are:

- 1 Thermocouple +ve
- 2 0v
- 3 Thermocouple -ve
- 4 n/c
- 5 n/c
- 6 Heater Output +ve
- 7 Heater Output -ve
- 8 Platinum Resistance Thermometer -ve
- 9 Platinum Resistance Thermometer +ve

*SAME
AT
PROBE
6 WAY
CONNECTOR*

The Heater Output connections are electrically isolated from the controller ground and from the power supply ground within the temperature controller.

The Input connections and the 0v connection on the 9 pin socket, share a common ground with the temperature controller electronics and are linked to the RS232 socket signal ground within the temperature controller. Both are isolated from power supply ground within the controller, though signal and power grounds may be linked within the computer.

It is important to note that the the room temperature compensating sensor for the main sensor thermocouple is mounted at the rear panel of the VTC. To get accurate compensation it is essential that the thermocouple reference junction is at the same temperature. This in turn means that the cable linking the probe to the VTC must use thermocouple compensating cable for

the main sensor leads. If the rear panel in the region of the connector is likely to be exposed to temperature fluctuations, it will be an advantage if a draught shield is placed around the plug, and the RT sensor, positioned immediately to its right.

3.3 Serial Data Line Connections

The bi-directional serial data link from the computer is connected via a 25 way D-socket on the rear panel.

Pin connections at this socket are:

2	Received Data (From Computer)
3	Transmitted Data (To Computer)
4	Linked to 5
5	Linked to 4
6	+5V when VTC is powered up
7	Signal Ground
8	+5V when VTC is powered up

All other pins are open circuit.

Voltage levels for the transmitted and received data are:

Tx Data High	> +5.5V
Tx Data Low	< -5.5V
Rx Data High Threshold	< +2.6V
Rx Data Low Threshold	> +1.4V
Max Rx Input Voltage	+/-30V

Data protocols are:

Baud Rate	9600
Tx Start Bits	1
Tx Data Bits	8
Tx Stop Bits	2
Rx Start Bits	1
Rx Data Bits	8
Rx Stop Bits	>=1

For normal ASCII exchanges the 8th data bit is treated as a parity bit. It is always set to "0" on transmitted data. It is ignored on received data.

3.4 Auxilliary Port Connections

The auxilliary port is provided primarily for the control of a gas solenoid. However it has up to 8 independant output lines and 4 input lines available. Connections to the port are by means of a 15-way D-socket on the rear panel.

The outputs are open-collector transistors. (Specification as for ULN2803A). These may be used to drive solenoids etc.

directly. The solenoids should be supplied from an external supply of 25 volts maximum and the maximum current per line should not exceed 500mA. The solenoid supply ground should be linked directly to the 0v pin of the Auxilliary socket.

Inductive loads such as solenoids must be protected by diodes to prevent the driver transistors being damaged by inductive spikes. This may either be achieved by individual diodes directly across the loads, or alternatively the +ve solenoid supply may be linked directly to pin 15 of the auxillary socket, in which case the protection diodes within the VTC will operate.

For low power loads, current may be drawn directly from pin 15, which is connected via a diode and fuse, to the internal unregulated 11 volt line. A maximum total current of 500mA may be drawn from this source.

The input lines on the auxilliary socket are suitable for either TTL level inputs or contact closures to 0v. The input device is a 74HC244 and 100K ohm pull-up resistors are fitted to the internal 5v line.

Pin connections at this socket are:

1	Output Bit 0
9	Output Bit 1
2	Output Bit 2
10	Output Bit 3
3	Output Bit 4
11	Output Bit 5
4	Output Bit 6
12	Output Bit 7
5	Input K4
13	Input K5
6	Input K6
14	Input K7
7	+5v
15	Driver Protection / +11v unregulated.
8	0v

4 OPERATION

4.1 First Time Operation

For first time operation it will be probably simplest to connect the VTC directly to a data terminal. Any terminal capable of operating at 9600 baud should be suitable. Once familiar with the operation of the various commands and responses, software may be written for the computer to perform the required functions.

With the terminal connected to the VTC the latter may be switched on using the POWER switch on the front panel. This switch should illuminate. If it fails to do so, check the power connection and the fuses.

At switch on, the VTC first performs a self test of its internal memory and its back-up battery. If all is well the display shows the message "PASS" for 2 seconds. If hardware errors are detected the message "Err" followed by a number is displayed for 10 seconds. If the back-up battery is aging the message "batt" is displayed for 10 seconds. (See below for the significance of this message).

On completion of the self test the display is blanked whilst the analogue circuits are given time to stabilise and the sensors are checked for error conditions.

If the sensors are within range the output safety relay is closed and the VTC enters its Stand-By state. In this state the STATUS indicator is unlit and the heater and gas-control solenoid are un-energised.

If a sensor error condition is encountered the relay is not closed and the status indicator flashes at a fast rate (2Hz).

In either case the display illuminates and indicates the measured probe temperature.

If the display blinks on then immediately goes out for another 1-2 seconds and continues to cycle on and off, check that the supply voltage is adequate. (The VTC automatically senses low supply volts and performs a reset function, to protect the data stored in memory). If necessary operate the instrument on a lower voltage setting.

Once the display is lit, the VTC should be fully operational. To test the serial link, type a "V" at the terminal (must be upper-case letters). The VTC should respond by sending two lines of text, describing the software and its version number. Provided this message is correctly printed the communication link is fully operational. The other commands given below may then be tried to gain familiarity with the system operation.

In the Stand-By state, manual control of the heater and gas solenoid is possible by means of the "O" and "G" commands. To

leave the Stand-By state and commence Automatic Control, the "A" command may be used. To provide full system operation, it will be necessary to have a VT probe connected with gas flowing. However most of the commands may be tested by placing a s/c across the thermocouple input terminals and a 100 ohm resistor across the safety sensor terminals.

Note that if an error condition is detected on the sensor assembly the safety relay may operate making it impossible to obtain any output. After clearing the problem the the "N" command may be used to reset the safety relay.

4.2 Communication Protocols

All dialogue with the computer is in 9600 baud serial form.

Data is sent as a start bit, 8 data bits plus two stop bits.

All normal user commands to the VTC and responses received, are sent as strings of ASCII characters. Where numeric values are required, these are also sent as ASCII strings representing the number in normal, decimal format. Numbers are preceded where appropriate by a "+" or "-" sign. To simplify interfacing, the VTC is fairly flexible in the format of numbers it will accept from the computer. Characters sent by the VTC have the MSB (parity bit) set to "0". If parity is sent by the computer it is ignored.

None of the Modem control lines of the RS232C interface are used. The VT controller will accept serial data at all times. In its default state it will only send data to the computer in response to a specific command. If however the computer is able to accept serial data at all times, the VT controller can be instructed to send a status message spontaneously whenever the status changes. This is done by means of the "Q" command, see below. The same command may also be used to control the sequence of characters returned by the VTC in response to a command. These may consist of any combination of:

- Single Letter Echo
- <CR> . Prompt String
- EOM character (ctrl-C)
- <LF> after all <CR>

If the computer used does not have adequate buffering it may be possible for messages from the controller to over-run this. To overcome this problem, the data rate from the controller may be slowed down to any chosen speed by means of the W command. This introduces a delay, before each character is sent. With this feature it is possible to accomodate computers with no input buffering.

4.3 Commands and Responses

Commands to the controller consist of a single upper case letter A-Z, optionally followed by a parameter sent as an ASCII decimal string. Where a parameter is required, it must be terminated by an ASCII <RETURN> character. <LINE FEED> characters, if sent are ignored. Commands not requiring a parameter, need no terminator. Only the single command letter is required. Again if a terminator is sent it will be echoed, but otherwise ignored.

The VTC may respond to a command to indicate that it has been correctly received. In some cases the response is to return a requested value. In cases where no other specific response is required, the controller may be instructed to remain silent, to echo the command letter or to issue a prompt string. In addition, if required the VTC may issue an EOM character after a command letter to indicate that its parameter may be sent. (It is however not necessary for the computer to await the EOM, the VTC will accept the parameter immediately after the command letter). merely echos the command letter.

Any commands which are not understood or cannot be obeyed in the current state of the instrument result in a "?" being echoed, followed by the command string as received. The "?" will always be the first character returned to simplify error handling by the computer. Again an EOM may optionally be sent following an error message.

Apart from responses to specific commands, the VTC will not normally issue messages. However another option in the Q command allows the VTC to send a status message spontaneously whenever the status changes.

Section 5 gives a list of the available commands and details of each.

5 COMMAND LIST

A list of all the currently active commands is given below, followed by a more detailed description of each of these,

In the list which follows the symbol n is used to indicate a decimal digit in the range 0-9.

1. COMMANDS NOT REQUIRING A PARAMETER

→	A	COMMENCE AUTOMATIC CONTROL
	M	RETURN TO MANUAL CONTROL
	B	RETURN TO STANDBY STATE
	R	SEND READING (MEASURED TEMPERATURE)
	E	SEND ERROR (BETWEEN MEASURED AND SET TEMPERATURES)
	H	SEND HEATER OUTPUT (Range 0-100%)
	S	SEND STATUS
→	V	SEND VERSION NUMBER FOR SOFTWARE
	C	INITIATE CALIBRATION DIALOGUE
	N	RESTORE NORMAL OPERATION

2. COMMANDS REQUIRING A PARAMETER & TERMINATOR

Tnnnnn	SET TEMPERATURE (See note 1)
Pn	SET PROPORTIONAL BAND (See note 2)
In	SET INTEGRAL ACTION TIME (See note 2)
Dn	SET DERIVATIVE ACTION TIME (See note 2)
Onnnnn	SET OUTPUT VOLTAGE (In MANUAL mode only)
Gnn	SET GAS SOLENOID (In MANUAL mode only)
Qn	SET "QUIET" STATUS (See Note 3)
Fnn	SET FRONT PANEL DISPLAY
Wnnnn	SET WAIT INTERVAL BETWEEN OUTPUT CHARACTERS
Unnnn	UNLOCK MEMORY PROTECTION

3. CHARACTERISATION AND DIAGNOSTIC COMMANDS

L	LOAD LINEARISER DATA TABLE
X	LOAD PATCH MEMORY
Y	LOAD WHOLE MEMORY
Z	DUMP WHOLE MEMORY

6. COMMAND SYNTAX

A COMMAND

The AUTO command sets the VTC into automatic control. It should be followed by a "T" command to select a desired temperature. After power-up or a "B" command the assumed set temperature will be 0.0 degrees. Otherwise the set point will remain at the last value selected. Note that it is possible to give the "T" command whilst in standby, but in this case the facility to automatically set the gas solenoid on the basis of the temperature requested will be lost. (See "T" command below).

→ M COMMAND

The MANUAL command returns the VTC from automatic to manual control. A fully "bumpless" auto-manual transition is effected. i.e. at switch-over the heater output is maintained at its current value and the state of the gas solenoid is unchanged. Similarly the transition from manual back to auto is also made "bumpless", by precharging the integrator to the current manual output. Thus if the temperature is being manually controlled at the desired set-point, there will be no change in heater output when switching to auto. (If the temperature is not at the set point when the switch to auto is made, there will of course be a change in output as the VTC attempts to move towards the set point).

B COMMAND

The BEGIN command performs a complete power-up and initialisation sequence, and returns the controller to the stand-by state with heater and gas solenoid both off. It is exactly equivalent to switching the controller off and then on again.

R COMMAND

The READ command instructs the computer to send the measured temperature. This is sent in the form of a signed integer giving the temperature in tenths of a degree, followed by a <CR> character.

E COMMAND

The ERROR command sends the temperature difference between measured and set temperatures in the same format.

H COMMAND

The HEATER command sends the heater voltage as a percentage of full output. (Note that this value is only approximate, it is not a calibrated parameter.)

S COMMAND

The STATUS command instructs the controller to send its current status. This is sent as a response consisting of S followed by a signed, single decimal digit and a <CR> character. Positive values of status indicate normal operation whilst a negative value normally indicates that a fault has been detected. When a negative status occurs, the output safety relay operates, to isolate the heater and prevent any possible damage to the VT probe. This relay may be reset by means of the "N" command (or by performing a calibration).

The following status reports are currently defined.

S+0	Control in Stand-By or Manual Control
S+1	Temperature Stable at Set Point
S+2	Temperature Changing
S+3	Safety Sensor limiting output
S-1	Gas not flowing or o/p stage fault (<i>turn up or check gas flow</i>)
S-2	Main Sensor on Bottom Limit
S-3	Main Sensor on Top Limit (o/c Thermocouple)
S-4	s/c Safety Sensor
S-5	o/c Safety Sensor

V COMMAND

The VERSION command results in the Software title, and version being sent as two lines of ASCII text, each terminated by a <CR>.

C COMMAND

The CALIBRATE command initiates a calibration dialogue where the controller issues messages requesting various input conditions to be applied, on the basis of which the internal calibration constants are set up. Once set, these are retained in non-volatile memory. Recalibration will normally only be necessary if sensors are changed or servicing work is carried out on the analogue portions of the controller.

To reduce the possibility of inadvertant loss of calibration, a "U" command is required before the "C" command will be recognised. See section 7.

N COMMAND

The NORMAL command restores a normal operation of the controller. Specifically it resets the output safety relay. Before issuing this command the cause of the relay operating should be investigated, and a "S" command issued to ensure that the controller is in a normal state. The "N" command also resets the front panel display to show Measured Temperature (equivalent to "F0" command).

Tnnnn COMMAND

The TEMPERATURE command instructs the controller to set a specific target temperature. Temperatures may be set in the range -150C to +200C. (The indication range is made larger than this to allow for overshoot etc.)

The format of the parameter following the T command has been made flexible to cope with a variety of computer output formats. The parameter required is a signed integer, representing the temperature in tenths of a degree. A decimal point, a +ve sign or leading zeros are all optional and will be ignored. However a digit for the tenths of degrees must be included even if this is zero. Thus the following formats will be accepted for a set temperature of 38.0 degrees.

```
38.0
0038.0
+ 38.0
380
```

whilst

```
38
38.
```

will be accepted but will give rise to a set point of 3.8 degrees. Other characters within a number will give rise to an error message.

If the "T" command is issued whilst under automatic control, the state of the Gas Control solenoid will be selected automatically on the basis of the temperature requested. For temperatures of 25.0 Celcius and below, the solenoid will be energised, to provide cooling. Above this temperature it will be un-energised.

If non-standard control of the gas solenoid is required, an "M" command should be issued to select the manual state, before issuing separate "T" and "G" commands to set the target temperature and gas solenoid respectively. Automatic operation may then be resumed by means of an "A" command.

Pn, Inand Dn COMMANDS

This family of three commands set the PROPORTIONAL, INTEGRAL and DERIVATIVE control terms. The commands are followed by a single digit specifying the value required, as shown in the following table. At power up the P,I and D values are set to defaults of 4, 4 and 0 respectively.

VALUE of n	P COMMAND	I COMMAND	D COMMAND
0	100%	32 min	OFF
1	50%	16 min	8 sec
2	25%	8 min	16 sec
3	12%	4 min	32 sec
4	6%	2 min	1 min
5	3%	1 min	2 min
6	1.5%	32 sec	4 min
7	-	16 sec	8 min
8	-	8 sec	16 min
9	-	4 sec	32 min

Onnnnn COMMAND

The OUTPUT command allows the output voltage to be set directly when in manual mode. (Status S=0). The command is not recognised in auto mode. The parameter may take values of 0 to 32767. (Note that output voltage is not directly proportional to nnnnn. There will be a dead bands at the end for which changes of nnnnn will not produce output changes.

Gnnn COMMAND

The GAS control command allows the state of the auxillary output port to be set directly when in manual mode. (Status S=0). The command is not recognised in auto mode. The parameter may take values of 0-255, allowing each of the eight lines of the auxilliary output port to be controlled directly. Each line is represented as ont bit of an 8-bit binary number. Any line that is active (i.e. pulled low) is represented by a binary 1. Then the required parameter nnn is the decimal equivalent of this 8-bit binary number.

In normal use only the least significant line is used, to control the gas solenoid. Hence the only two options will be G0 for solenoid off and G1 for solenoid energised.

Qn COMMAND

The "QUIET" command controls the responses generated by the VTC. The parameter n may take any value in the range 0-255. With n=0 or omitted. The VTC is totally quiet, the only data transfered

to the computer are the actual number strings in response to a measure command. Non-zero values for the parameter, result in a selection of any combination of 8 independent response options. Each is given a value (in a binary sequence) and the required Q parameter is obtained by adding together the values for each of the options required to be active. The list below shows the options available.

VALUE	OPTION
1	Echo Single Command letter on command-completed
2	Echo each character as received
4	Send "<CR>." prompt on command-completion or after STATUS sent automatically
8	Send <EOM> after initial command letter received
16	Send <EOM> after illegal-command error message
32	Send STATUS message whenever status changes
64	Send <EOM> after automatic status message
128	Send <LF> after every <CR>

At power-up the VTC is in the Q254 state, which is believed to be the state requested by Varian. ✓ (AS SHOWN ON ACQ DIAG PORT)

Fn COMMAND

The FRONT PANEL command determines which of the internal variables is displayed on the front panel LED display. The parameter normally displayed is measured temperature. For diagnostic purposes it can be useful to have a display of various other parameters. The following may be displayed:

F0	MEASURED TEMPERATURE
F1	SET TEMPERATURE
F2	ERROR (SET TEMP. - MEASURED TEMP.)
F3	HEATER VOLTS (AS A PERCENTAGE OF FULL OUTPUT)
F4	SAFETY SENSOR RESISTANCE (OHMS)
F5	RT SENSOR VALUE (DEGREES)
F6	CH1 INPUT FREQ/4
F7	CH2 INPUT FREQ/4
F8	CH3 INPUT FREQ/4
F9	P PARAMETER
F10	I PARAMETER
F11	D PARAMETER

NOTES

1. F2 is currently on an expanded scale (x20 approx) for diagnostic purposes.
2. The values for F3, F4 and F5 are approximate readings, intended for diagnostic purposes only.
3. F6, F7 and F8 provide a measure of the frequencies of the input V/F converters. Again these are intended for service diagnostic purposes only.
4. F9, F10 and F11 serve as a reminder of the current values of the P, I and D control parameters. Note that unlike the other values above, the displayed value is not continuously updated.

Thus after a P command it will be necessary to repeat the F9 command if the new value of P is to be displayed.

Wn COMMAND

The WAIT command is provided to simplify interfacing to slow computers, with no input buffering. For example a computer running a simple logging program in basic, may take several milliseconds between issuing an R command and being ready to accept the resulting response. The W command introduces a fixed delay before every character sent. The value of nnnnn specifies the delay in milliseconds. (Leading zero's may be omitted). Delays may extend from zero to 1 minute. (Though the latter is not recommended!).

Unnnn COMMAND

The VTC holds a number of key parameters in non-volatile memory. These can however be overwritten by specific sequences of commands, in order to reconfigure the instrument. To prevent erroneous commands causing such a corruption, a lock is built into the software. As supplied, the L, X and Y commands will not be recognised and produce an error message. To Unlock these commands the command Unnnn must be issued, where nnnn is the correct key-value.

To prevent inadvertant operator error a second lower level of locking is incorporated. This is used for example on the "C" command. At power up the command is locked but it can be unlocked by a U1 command. Almost any non-zero U parameter will open this lock. It is not necessary to know the full four digit key-value.

L COMMAND

The L command allows data to be sent to load the lineariser data table. The data is sent as a series of 257 decimal values in the range 0 to 65535. These represent the start and end points for the 256 segments into which the working range of the controller is divided. A relatively simple program written in Basic, is available from Oxford Instruments to transfer a data table from a computer to the VTC. To avoid the data table becoming corrupted by an inadvertant L command, this command is normally "locked" (see above).

X, Y & Z COMMANDS

This family of commands are provided purely for software diagnostic purposes. They transfer pure binary data (ie non-ASCII) between the controller and a computer. The X and Y commands overwrite areas of the non-volatile memory and could

therefore have a serious effect if misused. For this reason they are "locked". The Z command performs a binary RAM dump. It will produce confusing output at a terminal but can do no harm to the controller and is therefore left unlocked.

7. CALIBRATION

All linearisation data and calibration constants are held in NONVOL RAM (Mostek 480-Z-02, internal dual Lithium Battery with retention life >10 years). New linearisation tables can be loaded from the computer and all other calibration is handled by an interactive dialogue with the computer.

Minimal equipment required for a full calibration is:

- Millivolt Calibration Source
- Resistance box (to simulate safety sensor)
- Thermometer (to measure Room Temperature)
- 9600 Baud Terminal (or the spectrometer computer)

To reduce the chances of a calibration sequence being started inadvertently, the calibration command is "locked" at switch-on. Before calibration can take place a "U1" command must be given. (Almost any non-zero parameter will suffice, it is not necessary to know the unique key required for the "X" and "Y" commands).

Following the "U1" command, calibration is initiated by sending a "C" command. The VTC then conducts a dialogue in which it requests that various input conditions are applied in sequence. Once the specified condition has been applied the operator responds by pressing <RETURN>. After a pause to ensure that conditions have settled, the parameter is measured and the appropriate calibration constant is stored in non-volatile memory.

The calibration sequence is split into 3 sections covering the safety sensor, the main sensor and the room temperature sensor. Any section may be omitted by entering a <SPACE> rather than a <RETURN> for the first step of its sequence. However once a calibration sequence has been started for a sensor it must be completed. If any errors are made, the sequence for that sensor should be completed and then the calibration routine restarted to correct the error.

When calibration is complete, the "C" command may be relocked by means of a "U0" command. The "C" command automatically becomes locked if the instrument is switched off or if a "B" command is issued.

The following is an example of the calibration dialogue conducted in response to a C command. The operators responses are underlined and the symbol <RET> is used to denote a carriage return entered by the operator.

U1C

CALIBRATION SEQUENCE

Apply Input Condition specified, then press RETURN. To skip any step, press SPACE.

Safety Sensor = 20 ohms<RET>,wait
Safety Sensor = 210 ohms<RET>,wait
Safety Sensor = 199 ohms<RET>,wait
RT sensor TP = 0.35 volts<RET>,wait
RT sensor TP = 1.55 volts<RET>,wait
Isolate RT sensor TP<RET>,wait
Enter Room Temp in form XX.X 24.3<RET>
Main sensor = -5.603 mV<RET>,wait
Main sensor = +9.827 mV<RET>,wait
CALIBRATION COMPLETE

U0

means
Room
Temp

8. CALIBRATION CONSTANTS AND NOTES

ROOM TEMP SENSOR TEST POINTS

Voltages are applied between TP1 (+ve) and TP0 (-ve) on the input board. (The smaller board at the left-hand side of the instrument. Positions of the test points are shown on the PCB silk-screen.)

MAIN SENSOR INPUT VOLTAGES

(Apply these voltages direct to 9 way D socket. The calibration logic takes care of any RT corrections required.)

The values given calibrate the instrument for a range from -200C to +210C. In general it will not be possible to obtain readings down to -200C with the reference junction at room temperatures. The input amplifier will normally limit at around -190C. Calibration down to at least -150C is guaranteed with ambient temperatures up to 40C at the rear panel.

RESTORATION OF ORIGINAL CALIBRATION

If calibration has been lost for any reason and a suitable voltage source is not available, it may be expedient to restore the original calibration settings determined when the equipment was initially tested. To this end, a copy of the original calibration data is contained within the program memory EPROM U2. Use of this facility is described in section 10.3.

In instruments prior to serial number 07/006 this calibration data was supplied in a separate EPROM.

9. THEORY OF CONTROL

9.1 General

The aim of a controller is to maintain the temperature of a system as close as possible to some desired temperature (the SET POINT) and as far as possible to eliminate the effect of changes in the heat loss from the system. When a steady state is established, the heating provided by the controller will exactly balance the heat lost by the system to its surroundings. A further function of the controller is to follow any changes in the set point as rapidly as possible. Thus the criteria for good control are:

- CONTROL ACCURACY The mean temperature of the system should be as close as possible to the desired temperature.
- CONTROL STABILITY The fluctuations above and below the mean temperature should be small.
- CONTROL RESPONSE The system should follow changes in the set point as rapidly as possible.

In the following sections a number of possible control systems of increasing complexity are described, culminating in 3-TERM or P.I.D. control, as used in the VTC4.

9.2 Open Loop Operation

In an open loop system, a fixed heater power is applied and the system is allowed to come to equilibrium. There is no control as such, since the heater power can only be changed by the intervention of a human operator. The system takes a long time to reach equilibrium and any changes in the heat loss from the system, produce corresponding changes in the system temperature. The hot plates on a domestic cooker form an example of this form of "control". This mode of operation can be obtained with the VTC in its MANUAL mode.

9.3 On-Off Control

In an on-off (or "bang-bang") control system the heater power is either full on, if the temperature is below the set point; or off, if it is above. The control accuracy and response can be made very good with this form of control and the system can be made largely immune to changes in heat loss. However the control stability can never be made very good since the system temperature must always cycle above and below the set point. The magnitude of the temperature fluctuations depends on the thermal

properties of the system. For some systems, where temperature fluctuations are not important, this is a perfectly satisfactory and simple system of control. (e.g. the domestic electric oven).

9.4 Proportional Control

A proportional control system overcomes the problems of temperature cycling by allowing the heater power to be continuously varied. The heater voltage at any instant is proportional to the error between the measured and desired temperatures. Thus a large negative error will produce a large heater voltage in order to correct that error.

If the output voltage were proportional to the error over the whole range of the instrument, a negative error equal to half the total span of the instrument would be required in order to generate a full output voltage. Thus, although the control stability might be good, the accuracy would be very poor.

By increasing the GAIN of the controller the output can be made proportional to the error over part of the total range of the instrument. Outside this range the output is either fully on or completely off. The range over which the output is proportional to the input is the PROPORTIONAL BAND. This is normally expressed as a percentage of the total span of the instrument. Thus a Proportional band of 100% is equivalent to a gain of unity.

By reducing the proportional band, the accuracy of the controller may be improved since a smaller error will then be necessary to produce a given change in output.

This would seem to imply that, by sufficiently reducing the proportional band, any required accuracy could be obtained. Unfortunately as the proportional band is progressively reduced, there will come a point at which temperature oscillations reappear. (In the limit a controller with a proportional band of 0% is an on-off controller, as described above).

The reduction in proportional band which can be achieved before the onset of oscillations, will depend largely on the design of the system being controlled. In some systems it may be possible to achieve the required control accuracy without oscillations but in most cases this will not be so.

9.5 Integral Action

To overcome this problem, INTEGRAL ACTION is introduced. Consider a system controlled by proportional action as described above, with the proportional band sufficiently large to prevent oscillation. The result will be stable control but with a residual error between the measured and desired temperatures. Suppose this error signal is fed to an integrator, the output of

which is added to the existing controller output. The effect of this will be to vary the overall output until control is achieved with no residual error. At this point the input to the integrator will be zero and this will therefore maintain a constant output. Integral action has thus served to remove the residual error. Provided the contribution from the integrator is only allowed to vary slowly, proportional action will prevent the occurrence of oscillations. The response of the integrator is characterised by the INTEGRAL ACTION TIME. This is defined as the time taken for the output to vary from zero to full output, in the presence of a fixed error equal to the proportional band.

To ensure that the integrator itself does not give rise to oscillations, it is usual to employ an Integral Action Time of at least twice the response time constant of the system.

9.6 Derivative Action

The combination of Proportional and Integral Action will suffice to ensure that accurate and stable control can be achieved at a fixed temperature. However when the set point is changed many systems will tend to overshoot the required value. By means of Derivative Action this effect may be reduced or eliminated completely. Derivative Action monitors the rate at which the measured temperature is changing and modifies the control output such as to reduce this rate of change. (Derivative Action is exactly analogous to the use of velocity feedback in servo systems and serves the same function).

Like Integral Action, Derivative Action is characterised by an action time. If the measured temperature is changing at a rate of one proportional band per DERIVATIVE ACTION TIME, Derivative Action will contribute a signal sufficient to reduce a full output to zero or vice versa.

10 THE NON-VOLATILE MEMORY

All the sensor linearisation tables, calibration data and long-term parameters such as the prompt string are held in a non-volatile memory, so that they are retained when power is removed. This memory is contained in the integrated circuit U3 on the main circuit board.

Retention of the memory in the absence of power is achieved by means of a small lithium battery built into the memory package. Thus data is retained even when the integrated circuit is removed from its socket. The battery has sufficient capacity to retain the memory contents for at least 10 years.

Under exceptional circumstances, it is possible that some or all of the contents of the non volatile memory may be lost. Indications that this has occurred are a sudden change in calibration or a string of random characters, returned in place of the normal "." prompt, after every response.

Should this occur, follow the procedure given in section 10.3 below, to restore the calibration. If the fault re-appears after the instrument has been switched off, the non-volatile memory chip has failed and should be replaced.

10.1 "batt" warning message

Every time power is applied to the controller, internal circuitry within the memory tests the state of the battery. If this is starting to fail the normal "PASS" message obtained at power-up is replaced by a "batt" message. The letters are rather stylised and appear as:-

This message is held for 10 seconds instead of the normal 2 seconds. If this message is obtained, it is an indication that the memory chip needs replacing. There is a large voltage margin between the point at which the low battery warning is obtained and the point at which data is lost. Thus it will normally be possible to obtain and fit a replacement memory chip before data has been lost from the old one.

10.2 Memory Replication

If calibration data is not to be lost it is obviously necessary that the contents of the old memory chip must be copied into the new one. This may be done automatically by the VTC itself. The procedure to be followed is:

1. Disconnect the instrument from the mains supply and remove the top cover. (Once the four screws have been removed, the cover may be slid towards one corner, and the opposite corner lifted clear of the frame.)
2. Mark the old and new memory chips to avoid confusing them.
3. Carefully remove the program memory chip U2 from its socket and put it somewhere safe.
4. Carefully remove the old data memory chip U3 from its socket and install it in the U2 socket. Make sure it is the same way round. There will be a mark in one corner, or a notch at one end, which should be towards the front of the VTC. The data memory chip is a 24 pin device, whereas in later instruments the program memory chip is a 28 pin device. In this case the data memory chip should be mounted at the rear of the U2 socket, with the unused four positions towards the front of the instrument.
5. Install the new memory chip in the U3 socket. Again make sure it is the right way round.
6. Now reconnect the mains and switch the instrument on for 5 seconds, then switch it off again and disconnect from the mains once more. (Provided fingers are kept clear it is not necessary to replace the cover for this operation.). Apart from the mains indicator lighting, there will be no indication that anything is happening. The displays will not light. However a special piece of code contained within the memory chip will have copied its entire contents into the new chip.
7. Finally remove the old memory chip from the U2 socket and replace the original program memory chip in the socket. Replace the top cover and test the instrument. It should now operate normally and will still be fully calibrated.

10.3 Restoration of Original Memory Content

1 { If the calibration of an instrument has been lost for any reason, it is possible to restore the original calibration parameters determined during manufacture. On units from serial number 07/006 onwards, having software version 5.01 or later, this calibration data is incorporated in the program memory EPROM U2, which is a 28 pin device type 2764.



To restore the original calibration, the red button SW1 on the main PCB should be pressed, whilst the unit is switched on. Data from U2 will automatically be copied into U3.

2 { On instruments prior to serial number 07/006, with software version 4.xx, U2 is a 24 pin device type 2732. In this case the calibration data is written in a separate calibration EPROM supplied with the instrument.

To use this EPROM, follow the procedure given in section 10.2 but use the calibration EPROM in U2 socket rather than the old memory chip.

In either case it is important to use the correct calibration data for a specific instrument. Check that the label on the EPROM containing the calibration matches the serial number of the instrument it is to be used with.

SK301




SEGMENT ALLOCATION


IC	PIN	+5V	GND
U1	40	11	29
U2	28	28LK1	14
U3	28	28LK5	14
U4	28	24	5
U5	28	26	4
U6	14	14	7
U7	14	14	7
U8	16	16	8
U9	14	14	7
U10	14	14	7
U11	14	14	7


ROM	LK1	LK2
2732	1	1
2764	1	1
27128	2	1
27256	2	2

U3 RAH
 - reader
 linearisation
 tables
 - calibration
 de
 - long term
 parameter




COA.0202 (SHEET 1 OF 3)
 CPU, MEMORY AND TIMING






1:1
CORRESPONDENCE
WITH PROBE PJ6004

SK101




thermocouple in probe (J6004 1-3)
Gen III + early Gen IV $\approx 2k\Omega$ (1.6k - 2.2k Ω)
New Gen IV 1-3 $\leq 100\Omega$ ($\approx 7p$, 28 Ω)



SM2
AUX OP SOCKET
15 WAY D SOCKET

EQUIVALENT CIRCUIT OF OP
STAGE WITHIN VTC
8 IDENTICAL CIRCUITS CONTAINED
WITHIN U16



COA00200	VT CONTROLLER MAIN PCB ASSY	REFERENCE DESIGNATOR
COA0010	VTC PCB MOUNTING BLOCK	
COA0020	VTC MAIN PCB HAN. DETAILS	
ECC0182	CAP 47P CER N150 2A 63V	C1
ECC0210	CAP 82P CER N150 2A 63V	C2
ECC0347	CAP 100P CER N150 2A 63V	C6
ECC0510	CAP 4n7 CER HED-K 10A 63V	C206
ECC0510	CAP 100n MONOCER -20+80% 50V	C10-14, C16-20
ECP0610	CAP 1u0 POLYESTER 10A 100V	C203, 204
ECS0810	CAP 10u LOWLEAK ELEC 20A 50V	C3, C202
ECS0812	CAP 100u ELEC -10+50% 25V	C4, C201
ECS0822	CAP 220u ELEC -10+50% 63V	C205
ECS0832	CAP 220u ELEC -10+50% 16V	C5
ECS0842	DIODE 1H4003 400V 1A	D18D2
ECS0852	ZEHER 1H4750A BZX61 27V 1.3W	D201
ECS0862	FUSE 20mm CLASS QUICK 500mA	D202
ECS0872	FUSEHOLDEN 20mm PCB MTG	F1
ECS0882	FULL NUT B/ZH M3	
ECS0892	FEMALE SCREWLOCK (D TYPE)	
ECS0902	SCREW PAN-POZI B/ZH M2.5x6mm	
ECS0912	M3x10mm PAN-POZI B/ZH SCREW	
ECS0922	WASHER FIBRE M3.	
ECS0932	WASHER WAVY B/ZH M2.5	
ECS0942	WASHER WAVY B/ZH M3	
ECS0952	SELF ADHESIVE FOAM 25x12mm 0.8	
ECS0962	IC LP353 DUAL J FET AMP 8 DIL	U202
ECS0972	IC MC14526 COUNTER	U0
ECS0982	IC 74HC02H	U10
ECS0992	IC 74HC04H	U6
ECS1002	IC 74HC04H	U9&U11
ECS1012	IC 74HC04H	U7
ECS1022	IC 74HC137H	U12
ECS1032	IC 74HC144H	U14
ECS1042	IC 74HC273H	U13&U15
ECS1052	IC 74HC273H	U2
ECS1062	IC NOVRAH 2K X8 MK48Z02B	U3
ECS1072	IC OPTO-ISOLATOR 4N35 6 DIL	U201
ECS1082	IC 8251A USART	U5
ECS1092	IC 280A CPU	U1
ECS1102	IC 280A CTC	U4
ECS1112	IC MH234C TTL/MS232 C'INTERFACE	U17
ECS1122	IC OPTO DRAGON DRIVER ARRY 5V	U16
ECS1132	TEST POINT (SPACE INVADER)	TP'S
ECS1142	SOCKET IC TURNED PIN 24 DIL	
ECS1152	SOCKET IC TURNED PIN 28 DIL	
ECS1162	SOCKET IC TURNED PIN 40 DIL	
ECS1172	PLG AMP .100 PCB 3P 9	R15
ECS1182	PLG AMP .100" PCB 6P 9	R16

VT CONTROLLER FRONT PANEL ASSY	REFERENCE DESIGNATOR
VTC FRONT PANEL SUB ASSY	
INS BOOT 32mm FUSE (BLACK)	
BULB 14V HIGHLIGHT	
PLG TRI-DENT CABLE, 6WAY	
CONNECTOR PIN SIZE, 20 BICC	
SWITCH SERIES 31 II'LAND ROUND	
LENS ROUND RED, FOR ES23240	
WIRE JA 16/0.2 PVC BROWN	
WIRE JA 16/0.2 PVC BLUE	
WIRE JA 16/0.2 PVC VIOLET	
WIRE JA 16/0.2 PVC GREY	

PART NUM	DESCRIPTION	REFERENCE DESIGNATOR
COA1000	VT CONTROLLER FRONT PANEL ASSY	
COAL300	VTC FRONT PANEL SUB ASSY	
EPB3210	INS BOOT 32mm FUSE (BLACK)	
EPL1014	BULB 14V HIGHLIGHT	
EPH3306	PLG TRI-DENT CABLE, 6WAY	
EPT0520	CONNECTOR PIN SIZE, 20 BICC	
ESZ3240	SWITCH SERIES 31 II'LAND ROUND	
ESZ3242	LENS ROUND RED, FOR ES23240	
EWS0301	WIRE JA 16/0.2 PVC BROWN	
EWS0306	WIRE JA 16/0.2 PVC BLUE	
EWS0307	WIRE JA 16/0.2 PVC VIOLET	
EWS0308	WIRE JA 16/0.2 PVC GREY	
COA0010	VTC PCB MOUNTING BLOCK	
COA0300	VTC INPUT PCB HAN. DETAILS	
ECC0115	CAP 15P CER NPO 2A 63V	C107, 108
ECC0215	CAP 150P CER N150 2A 63V	C112, 113
ECC0510	CAP 100n MONOCER -20+80% 50V	C117, 118
ECP0510	CAP 100n POLYESTER 10A 100V	C106, 111
ECP0610	CAP 1u0 POLYESTER 10A 100V	C116
ECP0710	CAP 2u2 POLYESTER 10A 100V	C109, 114
ECS0810	CAP 10u LOWLEAK ELEC 20A 50V	C119
ECS0812	CAP 100u ELEC -10+50% 25V	C103, 104
ECS0822	CAP 220u ELEC -10+50% 16V	C115
ECS0832	CAP 470u ELEC -10+50% 16V	C105
ECS0842	CAP 1m0 ELEC -10+50% 40V	C101, 102
ECS0852	CAP 10u LOWLEAK ELEC 20A 50V	C110
ECS0862	CAP 220u ELEC -10+50% 16V	C122
ECS0872	CAP 470u ELEC -10+50% 16V	C120
ECS0882	CAP 1m0 ELEC -10+50% 40V	C121
ECS0892	CAP 10u LOWLEAK ELEC 20A 50V	C123
COA0300	VT CONTROLLER INPUT PCB ASSY	
COA0010	VTC PCB MOUNTING BLOCK	
COA0300	VTC INPUT PCB HAN. DETAILS	
ECC0115	CAP 15P CER NPO 2A 63V	
ECC0215	CAP 150P CER N150 2A 63V	
ECC0510	CAP 100n MONOCER -20+80% 50V	
ECP0510	CAP 100n POLYESTER 10A 100V	
ECP0610	CAP 1u0 POLYESTER 10A 100V	
ECP0710	CAP 2u2 POLYESTER 10A 100V	
ECS0810	CAP 10u LOWLEAK ELEC 20A 50V	
ECS0812	CAP 100u ELEC -10+50% 25V	
ECS0822	CAP 220u ELEC -10+50% 16V	
ECS0832	CAP 470u ELEC -10+50% 16V	
ECS0842	CAP 1m0 ELEC -10+50% 40V	
ECS0852	CAP 10u LOWLEAK ELEC 20A 50V	
ECS0862	CAP 220u ELEC -10+50% 16V	
ECS0872	CAP 470u ELEC -10+50% 16V	
ECS0882	CAP 1m0 ELEC -10+50% 40V	
ECS0892	CAP 10u LOWLEAK ELEC 20A 50V	
COA0300	VT CONTROLLER INPUT PCB ASSY	
COA0010	VTC PCB MOUNTING BLOCK	
COA0300	VTC INPUT PCB HAN. DETAILS	
ECC0115	CAP 15P CER NPO 2A 63V	
ECC0215	CAP 150P CER N150 2A 63V	
ECC0510	CAP 100n MONOCER -20+80% 50V	
ECP0510	CAP 100n POLYESTER 10A 100V	
ECP0610	CAP 1u0 POLYESTER 10A 100V	
ECP0710	CAP 2u2 POLYESTER 10A 100V	
ECS0810	CAP 10u LOWLEAK ELEC 20A 50V	
ECS0812	CAP 100u ELEC -10+50% 25V	
ECS0822	CAP 220u ELEC -10+50% 16V	
ECS0832	CAP 470u ELEC -10+50% 16V	
ECS0842	CAP 1m0 ELEC -10+50% 40V	
ECS0852	CAP 10u LOWLEAK ELEC 20A 50V	
ECS0862	CAP 220u ELEC -10+50% 16V	
ECS0872	CAP 470u ELEC -10+50% 16V	
ECS0882	CAP 1m0 ELEC -10+50% 40V	
ECS0892	CAP 10u LOWLEAK ELEC 20A 50V	

EMS0309 WIRE 3A 16/0.2 PVC WHITE
 EMT3095 CABLE TYRAP 2.5x95mm

2 LENGTHS
 CQA1400 VT CONTROLLER REAR PANEL ASSY

PART NUM	DESCRIPTION	REFERENCE DESIGNATOR
CQA1100	VTC TRANSFORMER MTG ASSY	
CQA1401	VTC REAR LABEL DETAILS	CQA1405
EHS0300	FULL HUT B/2H M3	
EHS1310	SCREW PAN-POZI B/2H M3x10mm	
EHS3300	WASHER STAR B/2H M3	
EHZ2015	IHS SLEEVE 20mmx1.5mm I/D BLK	
EZF3786	FILTER 240V AC FUSED F0378-6	

CQA1500 VTC INPUT/MAIN PC HARNESS
 PART NUM DESCRIPTION REFERENCE DESIGNATOR

EPR2014 SKT.IDC 14V STRATH RELIEF.
 EPR0114 RIBBON CABLE GREY 14 WAY

CQA1600 HEATSINK/TRANSISTOR ASSY
 PART NUM DESCRIPTION REFERENCE DESIGNATOR

CQA0420	HEATSINK JE-1 MACHINED 1.7c/W	
EHS0306	M3x6mm PAN-POZI B/2H SCREW	
EPM0203	SKT AMP .100 PCB 3P 5	
EPT0141	TR TIP141 0PM 125W 80V TO220	
EMS0151	WIRE 1.4A 7/0.2 PVC BROWN	
EMS0152	WIRE 1.4A 7/0.2 PVC RED	
EMS0153	WIRE 1.4A 7/0.2 PVC ORANGE	
LMT3095	CABLE TYRAP 2.5x95mm	
EW22015	IHS SLEEVE 20mmx1.5mm I/D BLK	
EZ51032	IHS WASH MICA TO3P	
EZ51033	IHS BUSH NYLON TO3P	

CQA0000 V.T. CONTROLLER FINAL ASSY
 PART NUM DESCRIPTION (EA) REFERENCE DESIGNATOR

CQA0020	VTC MTG. EHS 2U	
CQA0099	VT CONTROLLER SPARES KIT	
CQA0100	VT CONTROLLER DISPLAY PCB ASSY	
CQA0200	VT CONTROLLER MAIN PCB ASSY	
CQA0300	VT CONTROLLER INPUT PCB ASSY	
CQA1000	VT CONTROLLER FRONT PANEL ASSY	
CQA1400	VT CONTROLLER REAR PANEL ASSY	
CQA1500	VTC INPUT/MAIN PC HARNESS	
CQA1600	HEATSINK/TRANSISTOR ASSY	
EPA0200	TAPPED STRIP 81YE M2.5 (411mm)	
EIC2319	CASE HAMMOND 20x19"x261mm	
EHS0207	SCREW PAN-POZI B/2H M2.5x6mm	
EHS0306	M3x6mm PAN-POZI B/2H SCREW	
EHS0308	M3x8mm PAN-POZI B/2H SCREW	
EHS1211	SCREW CSK-POZI B/2H M2.5x10mm	
EHS8211	M2.5x10mm SCREW H'SKD CSK BLK	
EJH4201	WASHER WAVY B/2H M2.5	
EHS5201	WASHER STAR B/2H M2.5	
EHS5300	WASHER STAR B/2H M3	

CQA0099 VT CONTROLLER SPARES KIT
 PART NUM DESCRIPTION REFERENCE DESIGNATOR

CQA0999	VTC4 MANUAL	
EFP2300	FUSE 20MH GLAS ANTISURGE800N/A	
EFP2316	FUSE 20MH GLAS ANTISURGE 1.6A	

CQA0100 VT CONTROLLER DISPLAY PCB ASSY
 PART NUM DESCRIPTION REFERENCE DESIGNATOR

CQA0010	VTC PCB MOUNTING BLACK	
CQA0101	VTC DISPLAY PCB HAR. DETAILS	CQA010J
CQA1200	VTC DISP/MAIN PCB HARNESS	
ECS0822	CAP 220u BLEC -10.50V 16V	C301
EHL0002	LED GREEN STD .2"	LED301
EHS0207	SCREW PAN-POZI B/2H M2.5x6mm	
EJH4201	WASHER WAVY B/2H M2.5	
EIP5501	LED DIGIT 7 SEG .56 HE RED AN	LEDJ03-306
EIP5507	LED SIGN DISPLAY .56 HE RED AN	LED302
EIP2803	IC OPTO DRILGTON DRIVEN ARR 5V	U301
EPL0025	SOCKET IC TURNED PIN 24 DTL	
EPL0028	SOCKET IC TURNED PIN 28 DTL	
EPR0133	RES.NETWORK 8x33R D.I.L.	RJ302
EPR0218	RES.NETWORK 8x180R D.I.L.	RJ301
EYH0751	TR 2TX 751 PNP BI-POLAR	Q101-305

CQA1100 VTC TRANSFORMER MTG ASSY
 PART NUM DESCRIPTION REFERENCE DESIGNATOR

CQA1101	VTC TRANSFORMER MTG PLATE	
CQA1110	MTG. PLATE HARNESS SKT (VTC)	
ECU0510	CAP 100n MONOCER -20*80% 50V	C1102,1103
ECS0922	CAP 2m2 ELEC -10*50% 16V	C1101
ECS0947	CAP 4700uF ELEC -10*50% 63V	C1104
EHS0260	DIODE BRIDGE RECT. 6A 200V	D1101,1102
EHS0300	FULL HUT B/2H M3	
EHS0205	SCREW PAN-POZI B/2H M2.5x4mm	
EHS0304	M3x4mm PAN-POZI B/2H SCREW	
EHS0312	M3x12mm PAN-POZI B/2H SCREW	
EHS0405	SCREW PAN POZI D/2 M4x5mm	
EHS5300	WASHER STAR B/2H M3	
EHS4500	WASHER STAR B/2H M4	
EHS20000	SELF ADHESIVE FOAM 25x12mm	

EHS20005 CLAMP CAP (16mm DIA) BLACK
 EHS20009 CLAMP CAP .15mm DIA JO.
 EIV7805 IC VOLTAGE REG. 1A +5V
 ELS0001 TRANSFORMER VT CONTROLLER
 EPM0110 SOLDER TAG (EYELET) 4DA
 EPM0208 SKT AMP .100*PCB 8P 5
 EPM3206 SKT TRI-DEMT,CABLE,6 HAY
 EPT0420 CONNECTOR SKT SIZE 20 BICC
 ERP0368 RES WH 6K0 2.5W 5%

EMS0150	WIRE 1.4A 7/0.2 PVC BLACK	
EMS0150	WIRE 1.4A 7/0.2 PVC BLACK	
EMS0151	WIRE 1.4A 7/0.2 PVC BROWN	
EMS0152	WIRE 1.4A 7/0.2 PVC RED	
EMS0152	WIRE 1.4A 7/0.2 PVC RED	
EMS0153	WIRE 1.4A 7/0.2 PVC ORANGE	
EMS0154	WIRE 1.4A 7/0.2 PVC YELLOW	
EMS0101	WIRE 3A 16/0.2 PVC BROWN	
EMS0306	WIRE 3A 16/0.2 PVC BLUE	
EMS0307	WIRE 3A 16/0.2 PVC VIOLET	
EMS0310	WIRE 3A 16/0.2 PVC GREY	
EMS0310	WIRE 3A 16/0.2 PVC GRN/YLLW	
EMT2101	'P' CLIP SIZE N#1 BLACK	
EMT2102	'P' CLIP SIZE N#2 BLACK	
EWT3095	CABLE TYRAP 2.5x95mm	
EZ51220	IHS.WASH MICA TO220AU	
EZ51221	IHS.BUSH NYLON TO220AD	

PUT ON TOP OF ITEM 4
 U1101
 T1101
 SK6
 SK1101
 R1101
 HEAR